



0 0 0 0

## TRI LINE ACCENT for REAR TOUR PAK™ LIGHT

6910

### THANK YOU FOR CHOOSING KÜRYAKYN!

PROTECT YOURSELF AND OTHERS FROM POSSIBLE INJURY AND PROPERTY DAMAGE OR LOSS. PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS, AND NOTICES REGARDING THE INSTALLATION, USE, AND CARE OF THIS PRODUCT.

**WARNING** 

THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

**▲** CAUTION

This indication alerts you to the fact that ignoring the contents described herein can result in minor or moderate potential injury.

NOTICE

This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality or damage the product itself or the product to which it is being attached.

## MAKE SURE THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Top Accent
- 1 Left Accent
- 1 Right Accent
- 1 Antenna Plug
- 2 Alcohol Pads
- 1 Installation Instructions

## YOU WILL ALSO NEED:

Warm, soapy water and a clean rag, masking/painter's tape

NOTICE

These installation instructions contain important information. Ensure that the end user receives this copy and is aware of its importance for future reference.

- **STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn **IGN OFF.**
- STEP 2 Unthread the existing antenna(s) by turning them counterclockwise; remove and set aside for now.
- STEP 3 Refer to PIC 1. Using warm, soapy water and a clean rag, remove all dirt and debris from the installation area; allow the area to dry completely.



NOTICE

Avoid damage to the motorcycle. Protect painted surfaces with a soft cloth or blanket.

## **CUSTOMER SERVICE**

877.370.3604 (toll free)

#### **INSTALLATION QUESTIONS**

techsupport@kuryakyn.com or call 715.247.2983

#### LIMITED WARRANTY

Küryakyn warrants that any Küryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Küryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
  - •The product must be properly installed, maintained and operated under normal conditions.
  - Küryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Küryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Küryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breech of contract or duty between Küryakyn and a customer.
- Küryakyn products are often intended for use in specific applications. Küryakyn makes no warranty if a Küryakyn product is used in applications other than intended.
- •Küryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'S contained in components of Küryakyn products will be warranted for defects in materials and workmanship for 3 years from the date of purchase where as all other components shall be warranted for one(1) year. This includes, but is not limited to; control modules, wiring, chrome & other components.
- •Küryakyn makes no warranty of any kind in regard to other manufacturer¹s products distributed by Küryakyn. Küryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

#### **ABOUT OUR CATALOG**

For purchasing Küryakyn® products, you can receive a complete catalog free of charge.

Send the Proof-of-Purchase below with your address to: Küryakyn 454 County Road V V Somerset, WI 54025-9031

Somerset, WI 54025-9031
Please indicate either Accessories Catalog for
Harley-Davidson® or GL & Metric Cruisers.

Be sure to ask your local dealer about other Küryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Küryakyn USA® All Rights reserved.

PROOF OF PURCHASE

kuryakyn.com

# Küryakyn

## NOTICE

Ensure proper adhesion of this product. Remove all grease, oil, bugs, dirt, and other debris (including wax and polish) from the installation area. Kuryakyn will not provide warranty coverage on products or components lost or damaged due to improper installation.

Do not attempt this installation in temperatures below 50°F (10°C). Proper adhesive bonding ONLY occurs above 50°F (10°C).

STEP 4 Refer to PIC 2. Test fit the Left Accent as shown; use masking tape to make alignment marks; remove the Accent



**STEP 5** Refer to **PIC 3**. Test fit the Right Accent as shown.

Position the Accent over the edge of the Left Accent; use masking tape to make alignment marks; remove the Accent.



**STEP 6** Use your fingernail to rub the adhesive backing on the backside of the Left Accent; this will activate the adhesive. Remove and discard the backing.

**STEP 7** Align the Accent and press it into place for one minute; full bonding will occur after 24 hours. Remove and discard the masking tape.

**STEP 8** Repeat **STEPS 6 AND 7** for the Right Accent.

**STEP 9** Refer to **PIC 4**. Test fit the Upper Accent as shown; use masking tape to make alignment marks; remove the Accent.

**STEP 10** Prepare the adhesive backing on the Upper Accent in the same way as the others.



**STEP 11** Align the Accent and press it into place for one minute; remove and discard the masking tape.

**STEP 12** An Antenna Plug has been included in the kit for motorcycles WITHOUT a CB antenna.

Ensure the Top Accent is clean and dry;

prepare the adhesive as before and position the Plug over the exposed hole in the Top Accent; press into place for 60 seconds.

**STEP 13** Reinstall the antenna(s).



**PAGE** 

2

Ride On!

INSTALLATION