

INSTALLATION

TAILLIGHT COVER without SLOTS

9008

PARTS INCLUDED

1

- 1 Chrome Taillight Cover without Slots
- 2 Nylon Spacers
- 2 #8-32 x1-1/4" Phillips Pan Head Screws (PPHS)
 - Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

ATTENTION! This indication alerts you to the fact that ignoring the contents

described herein may negatively affect product performance and functionality.

14.104.0114.1

CAUTION! This indication alerts you to the fact that ignoring the contents

described herein can result in potential injury or material

damage.

TOOLS SUGGESTED

Phillips Head Screwdriver

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

Remove the two screws that secure the taillight lens to the base. PIC 1 Set



CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com or call 715.247.2983

LIMITED WARRANTY

Küryakyn warrants that any Küryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Küryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
 - •The product must be properly installed, maintained and operated under normal conditions.
 - Küryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- •Küryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Küryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breech of contract or duty between Küryakyn and a customer.
- Küryakyn products are often intended for use in specific applications. Küryakyn makes no warranty if a Küryakyn product is used in applications other than intended.
- •Küryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'S contained in components of Küryakyn products will be warranted for defects in materials and workmanship for 3 years from the date of purchase where as all other components shall be warranted for one(1) year.

 This includes, but is not limited to; control modules, wiring, chrome & other components.
- •Küryakyn makes no warranty of any kind in regard to other manufacturer¹s products distributed by Küryakyn. Küryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

For purchasing Küryakyn® products, you can receive a complete catalog free of charge.

Send the Proof-of-Purchase below with your address to: Küryakyn, P.O. Box 339, Somerset, WI 54025.

Please indicate either Accessories Catalog for Harley-Davidson® or GL & Metric Cruisers.

Be sure to ask your local dealer about other Küryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Küryakyn USA® All Rights reserved.





STEP 2

Küryakyn

STEP 3

Test fit the cover in place over the taillight lens, and check for clearance between the cover and the fender. PIC 2 If the cover touches the fender, it may cause damage to the paint; the spacers have been included to prevent the visor from contacting the fender.

NOTE:

If the cover does touch the fender, install the nylon spacers on the backside of the installation tabs by removing the adhesive backing on the spacer and placing them on the tabs as shown in PIC 3.


CAUTION!


Ensure that the cover will not touch the fender, which may result in damage to the paint. Küryakyn is not responsible for damage to paint/fender due to improper installation.

STEP 4

If the spacers are not needed place the cover over the taillight lens and secure the cover and lens with the OEM screws removed in Step 2. If the OEM screws **DO NOT** snug up the lens and cover in at **LEAST** three full turns, or if the spacers from Step 3 are used, use the included #8-32 x1-1/4" Phillips Head screws; **DO NOT OVER TIGHTEN** them or you may damage the cover or taillight lens.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not warranty components lost due to improper installation. Periodic maintenance may be required.





PAGE

Ride On!