

Installation instructions

Akrapovič Exhaust System: **Open** for the **Harley-Davidson** models: **Dyna**



www.akrapovic.com

Congratulations on purchasing an Akrapovič exhaust system. Please read the entire installation manual prior to undertaking any activities related to installation of your new Akrapovič exhaust system. In case you do not fully understand the manual or any of its parts, please contact your authorized dealer!

This product should be <u>installed by someone with sufficient knowledge</u> of exhaust systems and their installation, and appropriate hand or power tools. If you are not qualified for this work, please utilize a certified mechanic for installation. By installing Your Akrapovič exhaust system, you indicate that you have read the installation manual in its entirety and you agree with the terms stated herein.

It is your responsibility to <u>follow all installation instruction guidelines</u> supplied with the Akrapovič exhaust system and undertake all necessary safety precautions. Akrapovič d.d. assumes no responsibility for damages occurring from misuse, abuse, improper installation, improper operation, lack of responsible care, or all previously stated reasons resulting from incompatibility with other manufacturer's products and/or systems.

IMPORTANT INFORMATION

Exclusion of Certain Liability

- 1. The manufacturer, importer or dealer shall not be liable for any incidental damage including personal injury or any other damages caused by improper installation or operation of the Akrapovič exhaust system. When installing the Akrapovič exhaust system be careful that the exhaust system does not touch other parts sensitive to high temperature.
- 2. Akrapovič makes no representation or warranties with regard to damage caused by the improper installation, use and maintenance of the Akrapovič exhaust system. The warranty is limited to defects recognized by our technical department and due to normal use, and excludes items subject to normal wear (gaskets and damping wool). The guarantee is void in case of accident, modification, improper or competition use.
- 3. Do not attempt to install the Akrapovič exhaust system on a vehicle model for which it was not made or tested by Akrapovič.
- 4. When the exhaust system gets very hot during operation, be careful not to burn yourself on the exhaust system or parts which are in direct contact with it, even when the engine is not running. Also protect other people, especially children, from the injuries mentioned above.
- In some cases Akrapovič exhaust system kits contain chemical products (ceramic anti-seizing grease; bolt sealant). Handle with care, do not inhale or swallow. Avoid excessive contact with skin, eyes or mucous membranes. Keep out of reach of children.
- 6. Technical specifications of Akrapovič exhaust systems and related products are subject to change without notice.
- 7. <u>Before removing the original exhaust system</u> from your vehicle, please compare the parts you received with the list of materials provided in the installation manual in order to assure that you have all the parts necessary for the installation of your new Akrapovič exhaust system.
- 8. Although this manual consists of instructions for installation in written form, as well as photographs and pictures representing individual steps of the installation, please note that the photographs and pictures are symbolic and are intended for representation of general overview only. The <u>photographs and pictures</u> contained herein should serve as a guideline only and actual installation of the exhaust system may not correspond with the photographs and pictures entirely.
- The process of uninstalling the original exhaust system may vary depending on the existing exhaust system.
 Please follow the original exhaust system manufacturer's instructions for uninstalling the original exhaust system.

Trademarks

The Akrapovič Exhaust System Technology logo is a registered trademark of Akrapovič d.d.

Akrapovič website

Information about Akrapovič exhaust systems and related products is available on the Akrapovič website at: http://www.akrapovic.com/

Copyright

No part of the Akrapovič exhaust system or its documentation may be reproduced or distributed in any form or by any means without the prior written authorization of the Akrapovič company.

© Akrapovič, d.d. All rights reserved.

Symbols

The following symbols are used throughout these installation instructions:






USE BOLT SEALANT; Apply 3 to 4 small drops of bolt sealant onto the cleaned and degreased threads before tightening the bolts. **WARNING! Avoid contact with skin, eyes and mucous membranes. Do not inhale fumes. Keep out of reach of children.**



USE ANTI-SEIZE LEAD-FREE COPPER PASTE (black tube); Provides trouble-free and long-lasting protection against seizing, corrosion and rusting of bolts, threaded ends, nuts, joints, etc. Also protects against vibration, wear and impact. **WARNING! Avoid eye contact. Avoid excessive skin contact. Keep out of reach of children.**



USE ANTI-SEIZING GREASE (white tube); Prevents seizing, corrosion and excessive wear between the titanium components of your exhaust system. WARNING! Avoid eye contact. Avoid excessive skin contact. Keep out of reach of children.



- BEFORE INSTALLING, CHECK SCHEMATIC OF THE EXHAUST SYSTEM!
- IF ANY ITEMS IN THE AKRAPOVIČ EXHAUST SYSTEM PACKAGE ARE MISSING, PLEASE CONTACT YOUR AUTHORIZED DEALER. KEEP THE SCHEMATIC FOR FUTURE REFERENCE.
- THESE INSTALLATION INSTRUCTIONS MUST BE READ CAREFULLY IN ORDER TO ENSURE PROPER INSTALLATION AND OPERATION OF THE AKRAPOVIČ EXHAUST SYSTEM.
- THE EXHAUST SYSTEM CAN BE EXTREMELY HOT. ALLOW THE EXHAUST AND ENGINE TO COOL DOWN BEFORE BEGINNING INSTALLATION.
- WE ADVISE YOU TO LEAVE INSTALLATION TO A QUALIFIED SERVICEMAN. IMPROPER INSTALLATION MAY RESULT IN A SHORTER LIFETIME OF THE EXHAUST SYSTEM AND/OR DAMAGE TO THE VEHICLE.
- THIS MANUAL IS SPECIFIC TO THE HARLEY DAVIDSON DYNA STREET BOB. THERE MAY BE SOME DIFFERENCES IN INSTALLATION PROCEDURES FOR OTHER DYNA MODELS.
 - AKRAPOVIČ MAKES EVERY EFFORT TO PROVIDE IMPROVED CORNERING CLEARANCE FOR EXHAUST SYSTEMS. HOWEVER, DUE TO DESIGN AND SPACE LIMITATIONS ON SOME MOTORCYCLE MODELS, GROUND AND CORNERING CLEARANCE MAY NOT IMPROVE OR MAY EVEN BE REDUCED. FOR ADVANCED USERS, WE RECOMMEND INCREASING THE SPRING PRELOAD SETTINGS TO IMPROVE GROUND CLEARANCE.
- THE AKRAPOVIČ WARRANTY DOES NOT COVER DISCOLORATION OF ANY CHROME PRODUCTS.




REMOVAL OF ORIGINAL EXHAUST SYSTEM:

- 1. Put the motorcycle on a side stand, we recommend a center stand.
- 2. Remove the original mufflers, heat shields, header pipes and mufflers' brackets off the motorcycle.
- **INSTALLATION TIP:** check vehicle manufacturer manual for correct disassembly procedure.
- WARNING: make sure, not to damage any part of the motorcycle during this process!
- 3. For models with welded tubing original rear muffler's bracket only: remove the original bracket off the transmission housing.
- 4. For models with cast original rear muffler's bracket only: leave the original bracket on the transmission housing.
- 5. Remove the original exhaust valve cable from servo motor.
- **X** INSTALLATION TIP: check vehicle manufacturer manual for correct disassembly of valve cable.
- ! WARNING: do not turn the servo motor wheel with force, or the servo motor could be damaged!
- ! WARNING: do not disconnect the servo's electrical connector or remove the servo motor off the vehicle permanently (only during disassembly of exhaust valve cable)!
- WARNING: make sure, not to damage any part of the motorcycle during this process!

INSTALLATION OF THE AKRAPOVIČ EXHAUST SYSTEM:

- 1. For models with welded tubing original rear muffler's bracket only: screw the rear muffler's Akrapovič bracket onto the transmission housing, using original nuts and bolt (Figure 1).
- WARNING: make sure, not to scratch or damage any part of the motorcycle during this process!



- 2. Screw the front muffler's Akrapovič bracket onto the transmission housing, using original bolts (Figure 2).
- 1 WARNING: make sure, not to scratch or damage any part of the motorcycle during this process!




- 3. Hand tighten the header pipes onto the cylinder heads, using original nuts (Figure 3).
- CAUTION: we advise, that you use new original gaskets in the exhaust ports! 1
- WARNING: hand tighten the flanges only! Do not fully tighten them yet!
- ! WARNING: make sure, not to scratch or damage any part of the motorcycle during this process!





- 4. Tighten the lambda sensors into the front and rear headers (Figure 4).
- WARNING: grease only the threads of the lambda sensors with Akrapovič anti-seize lead-free copper paste!
- WARNING: make sure, not to damage the sensors or wiring harnesses!




- 5. Correctly assemble the clamps from Akrapovič installation kit, onto the mufflers' inlets (Figure 5).
- WARNING: use anti-seize copper paste on clamp bolt threads!
- CAUTION: leave the clamps unwound!



- 6. Slide the mufflers onto the header pipes. Align the mufflers and attach them to the mufflers' brackets using bolts, washers and nuts from Akrapovič installation kit (Figure 6, 7).
- WARNING: make sure, not to damage or scratch the brackets, mufflers or any other part of the motorcycle!








- 7. Align the header pipes and tighten both headers' flanges to the specified torque (Figure 8).
- CAUTION: before tightening the flanges make sure, that pipes don't touch the engine or any other part of the motorcycle!




- 8. Correctly assemble the tape clamps from Akrapovič installation kit onto the headers' heat shields, as shown (Figure 9).
- ! CAUTION: leave the tape clamps unscrewed!



- 9. Correctly attach both heat shields onto the headers, align them in respect to the pipes, mufflers and tighten the tape clamps and clamps at the header muffler joints to the specified torques (Figure 10, 11).
- CAUTION: make sure that lower heat shields' brackets are put between mufflers inlets and clamps correctly!
- WARNING: make sure, not to damage or scratch the heat shields, mufflers or any other part of the motorcycle!








INSTALLATION OF OPTIONAL AKRAPOVIČ SADDLE BAGS LIFT KIT:

- 1. Unscrew both original saddle bags off the motorcycle (Figure 12).
- WARNING: make sure, not to damage any part of the motorcycle during this procedure!



- 2. Assemble the Akrapovič brackets onto the motorcycle, using original distance bushes and bolts and washers from Akrapovič installation kit (Figure 13, 14).
- WARNING: make sure, not to damage any part of the motorcycle during this procedure!





- 3. Screw both original saddle bags onto the Akrapovič brackets, using M8x30 bolts and washers from Akrapovic installation kit (Figure 15).
- WARNING: make sure, not to damage any part of the motorcycle during this procedure!





Final installation:


Thoroughly clean all grease spots on headers, heat shields and muffler; use a soft cloth sprayed with a contact cleaner (brake cleaner), then wipe with a soft dry cloth.

Cleaning will prevent spots from burning onto the surface. Do not use aggressive chemical cleaners, because they can damage the logo/sticker.

- ! WARNING: make sure all the bolts are sufficiently tightened. In case the exhaust system touches the cowling or other parts, repeat the adjustment of the exhaust system or contact your authorized dealer.
- **WARNING:** check vehicle manufacturer manual for tightening torques (for dismounted stock parts)!
- IT IS NORMAL IF WHITE SMOKE COMES OUT OF THE MUFFLER ON FIRST OPERATION.
- DO NOT STAND BEHIND THE MUFFLER ON FIRST OPERATION.
- DO NOT USE AUTOMOTIVE WHEEL CLEANERS OR ANY CLEANING PRODUCTS WHICH CONTAIN ACIDIC ADDITIVES TO CLEAN AKRAPOVIČ EXHAUST SYSTEMS.

MAINTENANCE OF THE AKRAPOVIČ EXHAUST SYSTEM:

- Clean the titanium exhaust components with a multi-purpose spray lubricant (WD-40 or equivalent), carbon fiber exhaust components with soft and dry cloth and stainless steel, mortemp powder coated or chrome plated components with soft cloth sprayed with contact cleaner, then wipe with soft and dry cloth. A change in the color of the exhaust system is normal due to the high temperatures.
- 2. Periodically make sure all the bolts and springs are sufficiently tight.





www.akrapovic.com