

INSTALLATION INSTRUCTIONS Part Number: HD-1718

This filter fits: SEE CATALOG FOR CURRENT APPLICATIONS

* FREE K&N® decal To register your warranty, please see us online at knfilters.com/register. FREE K&N® decal *


Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N Filtercharger® seals properly.

If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.

INSTALLATION:

- 1. Disconnect the breather hose form the two breather bolts.
- 2. Remove the stock air filter from the air box
- 3. Remove the breather hose from the stock air filter. (fig. 1) NOTE: The K&N® air filter will utilize the OE breather hose (fig. 2)
- 4. Clean all sealing surfaces in the air box.
- 5. Install the OE breather hose onto the K&N® air filter (fig 3 and 4)
- 6. Install the provided washers onto the 3 stock bolts (fig 5)
- 7. Install the K&N® air filter into the air box, securing filter with the 3 bolts and washers (fig 6)
- 8. Connect the breather hose to the two breather bolts (fig. 7 and 8)

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.



CLEANING:

K&N Engineering, Inc., suggests checking the air filter element periodically for excessive dirt build-up. Depending on your driving conditions, we recommend cleaning your air filter every 50,000 miles. To clean and re-oil, purchase our filter Recharger® service kit, part number 99-5050 or 99-5000 and follow the easy instructions.