

# INSTALLATION INSTRUCTIONS PART NUMBER: SU-7086

#### **This Filter Fits:**

### SEE CATALOG FOR CURRENT APPLICATIONS

Congratulations, you have just purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jet-ting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N Air Filter seals properly.

#### **INSTALLATION:**

#### FRONT AIR FILTER INSTALLATION

- 1. Remove the stock air filter.
- 2. Carefully clean the air filter sealing surface.
- 3. Install the provided 3"OD gasket into the groove on the K&N Air Filter. (Fig. 1)
- 4. Install the K&N Air Filter into the air box following the D-shaped contour.
- 5. Install the three provided M4 washers on the three provided M4 bolts.
- 6. Install one of the provided spacers in between the air box and the K&N Air Filter. (Fig. 2)
- 7. Install the bolt and washer through the air filter plate and the spacer. (Fig. 3)
- 8. Repeat steps 6-7 for the two remaining holes.
- 9. Tighten the bolts evenly.

#### **REAR AIR FILTER INSTALLATION**

- 10. Remove the stock air filter.
- 11. Carefully clean the air filter sealing surface.
- 12. Install the provided 4-1/4"OD gasket into the groove on the K&N Air Filter. (Fig. 4)
- 13. Install the K&N Air Filter into the air box and line up with the holes in the air box.
- 14. Install the two provided M5 washers on the two provided M5 bolts.
- 15. Install the provided spacers in between the air box and the K&N Air Filter. (Fig. 5)
- 16. Install the bolt and washer through the air filter plate and the spacer. (Fig. 6)
- 17. Tighten the bolts evenly.

# THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.

# FRONT AIR FILTER:




Fig. 1




Fig. 2



Fig. 3

# **REAR AIR FILTER:**




Fig. 4




Fig. 5



Fig. 6